

Palert Plus
NTP IP Setting on PuTTY
and
NTP Server from PC


```
GNU nano 2.2.6 File: /etc/ntp.conf
pool.ntp.org maps to about 1000 low-stratum NTP servers. Your server will
# pick a different set every time it starts up. Please consider joining the
# pool: <http://www.pool.ntp.org/join.html>
#server 0.debian.pool.ntp.org iburst
#server 1.debian.pool.ntp.org iburst
#server 2.debian.pool.ntp.org iburst
#server 3.debian.pool.ntp.org iburst
#server 10.0.0.215 iburst minpoll 3 maxpoll 6

# Access control configuration; see /usr/share/doc/ntp-doc/html/accept.html for
# details. The web page <http://support.ntp.org/bin/view/Support/AccessRestricti$
# might also be helpful.
#
# Note that "restrict" applies to both servers and clients, so a configuration
# that might be intended to block requests from certain clients could also end
# up blocking replies from your own upstream servers.


# By default, exchange time with everybody, but don't allow configuration.

[ Read 56 lines ]
^G Get Help ^O WriteOut ^R Read File ^Y Prev Page ^K Cut Text ^C Cur Pos
^X Exit ^J Justify ^W Where Is ^V Next Page ^U UnCut Text ^T To Spell
```

- Type “sudo nano /etc/ntp.conf” command line in terminal, it will open a NTP config file, by this file, NTP server IP is capable to set in Palert Plus.
- Add “server IP iburst” for NTP time server.
- Ctrl + O for Write Out, Ctrl + X for exit, then push the button for 6 seconds to manual reloading.



- Please disable the windows Time service and close the fire wall(Or let NTP Tool sets into fire wall).



- Please enable NTP Tool and use “127.0.0.1” in it. After that click “Query” to start it.
- For example, windows IP sets as 192.168.255.3, the this is the NTP IP you have to set in ntp.conf from Palert Plus(see the 1 page in red color).
- Download website : <http://www.ntp-time-server.com/ntp-server-tool.html>

pi@raspberrypi: ~

```
login as: pi
pi@10.0.0.167's password:
```

```
The programs included with the Debian GNU/Linux system are free software;
the exact distribution terms for each program are described in the
individual files in /usr/share/doc/*/copyright.
```

```
Debian GNU/Linux comes with ABSOLUTELY NO WARRANTY, to the extent
permitted by applicable law.
```

```
Last login: Wed Sep  4 10:48:48 2019 from 10.0.0.51
```

```
pi@raspberrypi:~ $ nntp -pn
-bash: nntp: command not found
```

```
pi@raspberrypi:~ $ ntpq -pn
```

remote	refid	st	t	when	poll	reach	delay	offset	jitter
+173.249.41.242	17.253.54.251	2	u	56	64	377	284.325	-5.383	1.948
+183.177.72.202	119.160.254.155	2	u	19	64	377	2.193	0.468	0.388
+118.163.170.6	216.239.35.0	2	u	34	64	377	2.379	0.046	0.505
*220.133.209.243	211.22.103.157	3	u	50	64	377	2.116	-0.088	0.362

```
pi@raspberrypi:~ $
```

- Type “ntpq -pn”, when you have NTP, you will see a “*” in front of functioning IP.