Palert Plus Firmware Update

You need

1. win_SCP
2. Tcptools
3. Hexadecimal to decimal tool

WinSCP : 1. user name: pi
2. Password: 1111



Path : /home/pi/Desktop/vAlert/bin/paInt.exe



Left side : your laptop

Right side : Palert Plus

Firmware update ..
/home/pi/Desktop/vAlert/bin




bin - pi@192.168.255.1 - WinSCP
Local Mark Files Commands Session Options Remote Help
Default
pi@192.168.255.1
C:\Users\jeremy\Desktop
/home/pi/Desktop/vAlert/bin
paInt.exe Properties
Common
Checksum
1 file
Location: /home/pi/Desktop/vAlert/bin
Size: 723 KiB (740,263 B)
Group: pi [1000]
Owner: pi [1000]
Permissions:
Owner R W X Set UID
Group R W X Set GID
Others R W X Sticky bit
Octal: 0755
755
OK
Cancel
Help
0 B of 399 MiB in 0 of 90
0 B of 30,403 KiB in 0 of 121
F2 Rename F4 Edit F5 Copy F6 Move F7 Create Directory F8 Delete F9 Properties F10 Quit
SFTP-3
1:20:56

Palert Plus Firmware Update

You need

1. win_SCP
2. Tcptools
3. Hexadecimal to decimal tool

RELOAD PARAMETERS!



RELOAD PARAMETERS!



RELOAD PARAMETERS!



Click “send”

RELOAD PARAMETERS!



Reloaded when “Linked” become “Link”

Palert Plus Firmware Update

You need

1. win_SCP
2. Tcptools
3. Hexadecimal to decimal tool

CHECK
FIRMWARE VERSION

1. Insert IP
2. Click Link bottom
3. Change numbers
4. Click send bottom
5. Copy numbers



CHECK
FIRMWARE VERSION

Paste “01 9B” and click “Convert”

This is your firmware version

https://www.binaryhexconverter.com/hex-to-decimal-converter